

Quickguide Basic badebænk med håndtag

Assembly

Step 1. Place seat upside down on a flat surface.

Step 2. Fix crossed base tubes with seat using five wing screws with washers.

Step 3. Join base tubes with legs.

HEIGHT ADJUSTMENT

- To adjust the height of the shower chair, press metal pin, select appropriate height of leg, and lock the position of the tubes relative to each other with the use of metal pin. The legs are adjustable in 2.5 cm increments.

Note! The pins must be set on the same level in each leg.