

HOW TO UNFOLD




PUSH



! STEP 1

PUSH THE CUSHION TUBE BACKWARDS TO FULLY CLOSE THE FRAME



! STEP 2

IF YOU CAN NOT UNLOCK THE FRAME , REPEAT THE STEP ONE



PRESS



! STEP 3

PRESS THE CUSHION TO UNFOLD THE FRAME



ROTATE



! STEP 4

UNFOLD THE ANTI-TIPPING WHEELS AND BACKREST